


BCO1

Exploded parts diagram







Part Number	Number	Description	Qty
***	1	Lower Beam	1
B3-ZYXD1A002	2	Outer Toughened Glass	1
***	3	Bolt	1
***	4	Side Post	1
B3-ZYXD1A0051	5	Door Hinge	2
***	6	Bolt	1
B3-ZYXD1A007	7	Handle End	1
B3-ZYXD1A008	8	Inner Toughened Glass	1
***	9	Bolt	1
B3-ZYXD1A010	10	Thermostat Knob	1
***	11	Thermostat Switch Base	1
B3-ZYXD1A012	12	Heating Indicator Lamp	1
B3-ZYXD1A013	13	Power Indicator Lamp	1
B3-ZYXD1A014	14	Timer Knob	1
***	15	Base	1
***	16	Lower Front Plate	1
***	17	Bottom Plate	1
B3-ZYXD1A018	18	Timer	1
B3-ZYXD1A019	19	Feet	4
***	20	Grounding Bolt	1
***	21	Jacket	1
***	22	Power Cord	1
B3-ZYXD1A022	23	Temperature Limiter	1
***	24	Grounding Bolt	1
B3-ZYXD1A020	25	Thermostat	1
***	26	Frame Bracket	1
***	27	Frame	1
B3-ZYXD1A0281	28	Hinge Stay	2
***	29	Screw	1
***	30	Back Insulation	1
***	31	Thermal Insulation	1
***	32	Casing	1
***	33	Back Cover	1
B3-ZYXD1A034	34 & 41	Motor and Blade	1
B3-ZYXD1A035	35	Rubber Seal Door	1
B3-ZYXD1A036Z	36 & 38	Lamp Holder	1
B3-ZYXD1A037	37	Lamp	1
B3-ZYXD1A036Z	38	See 36	1
B3-ZYXD1A039	39	Heating Element	1
***	40	Fixed Bolt	1
B3-ZYXD1A034	41	See 34	1
***	42	Fixed Nut for Fan	
***	43	Internal Plate	1
***	44	Racking	1
***	45	Upper Door Beam	1
B3-ZYXD1A046	46	Handle	1
***	47	Screw	1
B3-ZYXD1AA06	1,9,45,47	Complete Door	1
B3-ZYXD1AA01		Tray	1
B3-ZYXD1AA02		Shelf	3

*** Please contact Spares for assistance ***